

FLAVORS AVAILABLE

















200 UP TO PUFFS **18ML**



OIL COIL SEPARATION DESIGN

BEFORE USE

Step 1:

Pull out of the rubber rod from mouthpiece, And tear off the bottom sticker.

Step 2: Wait 120 seconds(2 minutes) letting oil getting into the coil.





RGB COLOR FLASH LIGHT

While inhaling, oil tank with colorful RGB flashlight.















FILLING INSTRUCTION

1. Pull up the nozzle cover.

2. Open the filling rubber and inject oil into the filling hole.





Note:

To provide you the better taste, please replace the oil-absorbing cotton when half of the e-liquid is used.

After the e-liquid is used up, please refill the e-liquid and replace the oil-absorbing cotton, the taste will be better.





INDICATOR



Green Light, Power >70%




Blue Light, 70% < Power > 30%



Red light, Power< 30%


Note: When fully charged, the green indicator light is off, unplug the USB, the green indicator light flashes 3 times and goes off.





O.8Ω MESH COIL











ADJUSTABLE AIRFLOW





SPECIFICATIONS

VOLTAGE: 3.6V

COIL RESISTANCE: 0.8 OHM

POWER RANGE: 16W

E-ELIQUID CAPACITY: 18 ML

PRODUCTION SIZE: 91.5 * 30 * 30MM

BATTERY CAPACITY: 650MAH (RECHARGEABLE)

ADJUSTABLE AIRFLOW





GRA

GRAPE ICE









LON







SION JAVA















RRYRRY